


LIGAMENTOTAXOR®

LIGAMENTOTAXOR®
Adjustable distraction!

Quick and easy to use
2 possible assemblies: short or long blue plastic wires.



« Long » green plastic wires

« Short » blue plastic wires

LIGAMENTOTAXOR® Kit description
(double sealed sterile pack - single use)

- 2 « long » green plastic wires
- 2 « short » blue plastic wires
- 2 KW Ø: 1.2 mm
- 1 KW Ø: 1.5 mm (« U » shape frame)
- 2 springs with open ends
- 4 KW tip protections
- 1 single use drill guide




DISTRIBUTED BY
J.B. Implants Services bv
Robijnborch 7
5241 LK Rosmalen
www.jb-implants.nl
T 073 52 20780
F 073 52 21245
E info@jb-implants.nl


Manufacturer:
AREX®
BP20
3 Allée du Clos Tonnerre
F91125 Palaiseau cedex FRANCE

www.alex.fr

AREX®_BP 20 - P91125 PALAISEAU cedex FRANCE — T. +33 [0] 169 412 212 _ F. +33 [0] 169 411 110 _ info@alex.fr



ADJUSTABLE DISTRACTION





ASSEMBLY



www.alex.fr/Ordre/AREX-LIGAMENTOTAXOR.mp4


LIGAMENTOTAXOR[®]

Palmar sub-luxation with a 3rd KW



Please note it is still possible to adjust LIGAMENTOTAXOR[®] traction even after placement of a third KW.

LIGAMENTOTAXOR[®]



- Small spacer for normal size finger anatomy.
- LARGE spacer for longer anatomy. Large Spacer may permit lateral X-Rays joint visibility.




Quick video to present LIGAMENTOTAXOR[®]
www.alex.fr/QRc/AREX-LIGAMENTOTAXOR.mp4




Detailed video to present MANOTTE[®]1.6TB pliers
Bend / Cut / Crimp
www.alex.fr/QRc/MANOTTE16TB.mp4

LIGAMENTOTAXOR®



ASSEMBLY




ADJUSTABLE DISTRACTION

Design+photo: e-monceaux / Réf. 065 éd.11 - © AREX® - 2017

LIGAMENTOTAXOR®

Adjustable distraction!

Quick and easy to use.
2 possible assemblies: SHORT or LONG plastic wires



LIGAMENTOTAXOR® Kit description:

Double sealed sterile pack - single use

- 2 long green plastic wires
- 2 short blue plastic wires
- 2 KW Ø: 1.2mm
- 1 KW Ø: 1.5mm («U» shape frame)
- 2 springs with open ends
- 4 KW tip protections
- 1 single use drill guide



A single use drill guide
to ensure KW parallel placement.

CE 0495

DISTRIBUTED BY

J.B. Implants Services bv
Robijnborch 7
5241 LK Rosmalen
www.jb-implants.nl

Manufacturer:
AREX®
BP20
3 Allée du Clos Tonnerre
F91125 Palaiseau cedex FRANCE

www.arex.fr

AREX® _ BP 20 - F91125 PALAISEAU cedex FRANCE — T. +33 [0] 169 412 212 _ F. +33 [0] 169 411 110 _ info@arex.fr


1

AREX®
Stay the course


INSTRUCTIONS FOR USE of LIGAMENTOTAXOR® (most cases)

For optimal use MANOTTE®1.6TB
and Drill guide are mandatory.


www.alex.fr




First, put in place proximal 1.2mm KW [1]. Then use disposable drill guide [2] to ensure parallel placement of 2nd (distal) KW [3].




Open MANOTTE®1.6TB pliers as wide as possible and place under the hand. Bend the distal KW at a 90° angle on both sides of the finger [4].




Cut bent distal KW and place outwards along the finger. See photo above.




Slide blue plastic rods over proximal KW on both sides of the finger. **SELECT THE END OF THE SPRING WITH THE LONGEST STRAIGHT END.** Screw each spring completely over both distal KWs and blue plastic rods as shown [5]. The spring end will lock automatically. If extra traction is required, unscrew the spring away from the blue plastic rod. Pull distally while re-screwing.



Bend proximal 1.2mm KW at 90° on each side [6]. Be sure to leave sufficient space to allow blue plastic rods to rotate without rubbing against the finger. Distribute the space left by MANOTTE® on each side equally, as shown on 7, 8, 9 photos.



Cut proximal KW as shown, then place KW protective caps as shown and finally crimp them into place.



To stabilise both springs, construct a "frame" using the 1.5mm KW supplied [0.059in.] creating a U-shape large enough to maintain the springs away from the finger. If necessary, springs can be shortened before constructing the U-shaped frame.

Two strips of tape can be placed around both the springs and the U-shaped frame to secure selected distraction. The number of spring turns between the proximal and distal KWs can be noted on the tapes.


J.B. Implants Services bv

Robijnborch 7 T 073 52 20780
5241 LK Rosmalen F 073 52 21245
www.jb-implants.nl E info@jb-implants.nl

CE 0499

AREX® BP 20 - F91125 PALAISEAU cedex FRANCE — T. +33 [0] 169 412 212 _ F. +33 [0] 169 411 110 _ info@alex.fr


IMPORTANT REMINDERS FOR SURGEONS USING THE LIGAMENTOTAXOR® = LTX




Please note there are two different sizes of blue spacers.



Insert flat part of spring first onto LIGAMENTOTAXOR®.



- SMALL SPACER for normal size finger anatomy.
- LARGE SPACER for longer anatomy. Large Spacer may permit lateral X-Rays joint visibility.



Don't forget to use 1.5 mm K-wire for U-Shape Stabilizer.

www.arem.fr